

STRUCTURE

Silicon Monolithic Integrated Circuit

NAME OF PRODUCT

DC-AC Inverter Control IC

**TYPE** 

BD9888F、BD9888FV

**FUNCTION** 

- · 2ch control with Push-Pull
- · Lamp current and voltage sense feed back control
- · Sequencing easily achieved with Soft Start Control
- · Short circuit protection with Timer Latch
- · Under Voltage Lock Out
- Short circuit protection with over voltage
- Mode-selectable the operating or stand-by mode by stand-by pin
- · Synchronous operating the other BD9888F or BD9888FV IC's
- BURST mode controlled by PWM and DC input
- · Short circuit protection with voltage difference detection

## OAbsolute Maximum Ratings (Ta = 25°C)

Parameter	Symbol	Limits	Unit	
Supply Voltage	VCC	15	٧	
Operating Temperature Range	Topr	-40~+90	°C	
Storage Temperature Range	Tstg	<b>-55∼+125</b>	°C	
Power Dissipation	Pd	600*1 (BD9888F)	mW	
rower Dissipation	ru	850*2 (BD9888FV)		
Maximum Junction Temperature	Tjmax	+125	°C	

<sup>\*</sup>¹Pd derate at 6.0mW/°C for temperature above  $Ta = 25^{\circ}$ C (When mounted on a PCB 70.0mm $\times$ 70.0mm $\times$ 1.6mm) \*²Pd derate at 8.5mW/°C for temperature above  $Ta = 25^{\circ}$ C (When mounted on a PCB 70.0mm $\times$ 70.0mm $\times$ 1.6mm)

## ORecommended operating condition

Parameter	Symbol	Limits	Unit
Supply voltage	VCC	5.0~14.0	V
CT oscillation frequency	fCT	20~150	kHz
BCT oscillation frequency	fBCT	0.05~0.50	kHz

# Status of this document

The Japanese version of this document is the official specification.

Please use the translation version of this document as a reference to expedite understanding of the official version. If these are any uncertainty in translation version of this document, official version takes priority.




○Electric Characteristics (Ta=25°C, VCC=7V)

Parameter Parameter		Limits			llm: A	Candidiana
	Symbol	MIN.	TYP.	MAX.	Unit	Conditions
((WHOLE DEVICE))						
Operating current	Icc1	_	11.0	17.0	mA	CT=0.5V
Stand-by current	Icc2		2	10	μA	
((OVER VOLTAGE DETECT))					_	
FB over voltage detect voltage	Vovf	2.20	2.40	2.60	V	
((STAND BY CONTROL))						
Stand-by voltage H	VstH	1.6	_	VCC	٧	System ON
Stand-by voltage L	VstL	-0.3		0.8	٧	System OFF
Stand-by hysteresis	⊿Vst	0.08	0.18	0.28	٧	
((TIMER LATCH))						
Timer Latch voltage	Vcp	1.9	2.0	2.1	٧	
Timer Latch current	lcp	0.5	1.0	1.5	μΑ	
((BURST MODE))						
BOSC Max voltage	VburH	1.94	2.0	2.06	V	fBCT=0.2kHz
BOSC Min Voltage	VburL	0.4	0.5	0.6	V	fBCT=0.2kHz
BOSC constant current	IBCT	1.35/BRT	1.5/BRT	1.65/BRT	A	
BOSC frequency	fBCT	266	280	294	Hz	BRT=33k $\Omega$ 、BCT=0.050 $\mu$ F
((OSC BLOCK))						
OSC constant current	ICT	1.35/RT	1.5/RT	1.65/RT	Α	
OSC Max voltage	VoscH	1.8	2.0	2.2	V	fct=60kHz
OSC Min voltage	VoscL	0.3	0.5	0.7	٧	fct=60kHz
MAX DUTY	MAXDUTY	44	46.5	49	%	fct=60kHz
Soft start current	Iss	1.0	2.0	3.0	μΑ	
IS COMP detect Voltage	Visc	0.45	0.50	0.55	V	<del> </del>
SS COMP detect voltage	Vss	2.0	2.2	2.4	i v	
SRT ON resistance	RSRT		200	400	Ω	
((UVLO BLOCK))	1 10	<u> </u>				1
Operating voltage	VuvloH	4.100	4.300	4.500	Τv	
Shut down voltage	VuvToL	3.900	4.100	4.300	V	
((REG BLOCK))			•	<u> </u>	•	
REG output voltage	VREG	3.038	3.100	3.162	٧	
REG source current	IREG	5.0		-	mA	
VREF voltage	VREF	1.225	1.250	1.275	٧	VREF=0pen
((FEED BACK BLOCK))						
IS threshold voltage	Vis	1.225	1.250	1.275	V	
VS threshold voltage	Vvs	1.220	1.250	1.280	٧	
IS source current 1	lis1	_	_	1.5	μΑ	DUTY=2.0V
IS source current 2	lis2	13.0	20.0	27.0	μΑ	DUTY=0V、IS=0.5V
VS source current	lvs		_	1.0	μΑ	
((OUTPUT BLOCK))		•			· · · · ·	
NAch output voltage H	VoutNAH	VCC-0.3	VCC-0.1	_	٧	
NBch output voltage H	VoutNBH	VCC-0.3	VCC-0.1		٧	
NAch output voltage L	VoutNAL	_	0.1	0.3	V	
NBch output voltage L	VoutNBL		0.1	0.3	٧	
NAch output sink resistance	RsinkNA	_	5	10	Ω	Isink = 10mA
NAch output source resistance	RsourceNA	<del>-</del>	8	16	Ω	Isource = 10mA
NBch output sink resistance	RsinkNB		5	10	Ω	Isink = 10mA
NBch output source resistance	RsourceNB		8	16	Ω	isource = 10mA
Drive output frequency	four	58.5	60.0	61.5	KHz	RT=18kΩ、CT=395pF
((COMP BLOCK))						
Under voltage detect	VCOMPL	0.620	0.640	0.660	V	
Voltage difference detect	△VCOMP	0.40	0.45	0.5	v	VCOMPA-VCOMPB


(This product is not designed to be radiation-resistant.)



## OPackage Dimensions



OBlock Diagram



OPin Description

Pin No. Pin Name Function  1 DUTY Control PWM mode and BURST mode  2 BRT External resistor from BRT to GND for adjusting the BURST triangle oscillator  3 BCT External capacitor from BRT to GND for adjusting the BURST triangle oscillator  4 RT External resistor from SRT to RT for adjusting the triangle oscillator  5 SRT External resistor from SRT to RT for adjusting the triangle oscillator  6 CT External capacitor from CT to GND for adjusting the triangle oscillator  7 GND GROUND  8 FB1 Error amplifier output①  9 IS1 Error amplifier input②  10 VS1 Error amplifier input②  11 FB2 Error amplifier input②  12 IS2 Error amplifier input②  13 VS2 Error amplifier input④  14 VREF Reference voltage  15 COMPA1 Voltage difference or under voltage detect for 1ch  16 STB Stand-by switch  17 COMPB1 Voltage difference or under voltage detect for 1ch  18 COMPA2 Voltage difference or under voltage detect for 2ch  19 COMPB2 Voltage difference or under voltage detect for 2ch  20 REG Internal regulator output  21 SS External capacitor from SS to GND for Soft Start Control  22 SCP External capacitor from SCP to GND for Timer Latch  23 NA2 FET driver for 2ch  24 NB2 FET driver for 2ch  25 PGND Ground for FET drivers  26 NB1 FET driver for 1ch  27 NA1 FET driver for 1ch  28 Vcc Supply voltage input					
2 BRT External resistor from BRT to GND for adjusting the BURST triangle oscillator  3 BCT External capacitor from BCT to GND for adjusting the BURST triangle oscillator  4 RT External resistor from SRT to RT for adjusting the triangle oscillator  5 SRT External resistor from SRT to RT for adjusting the triangle oscillator  6 CT External capacitor from CT to GND for adjusting the triangle oscillator  7 GND GROUND  8 FB1 Error amplifier output①  9 IS1 Error amplifier input①  10 VS1 Error amplifier input②  11 FB2 Error amplifier input②  12 IS2 Error amplifier input②  13 VS2 Error amplifier input④  14 VREF Reference voltage  15 COMPA1 Voltage difference or under voltage detect for 1ch  16 STB Stand-by switch  17 COMPB1 Voltage difference or under voltage detect for 1ch  18 COMPA2 Voltage difference or under voltage detect for 2ch.  19 COMPB2 Voltage difference or under voltage detect for 2ch.  20 REG Internal regulator output  21 SS External capacitor from SS to GND for Soft Start Control  22 SCP External capacitor from SCP to GND for Timer Latch  23 NA2 FET driver for 2ch  24 NB2 FET driver for 2ch  25 PGND Ground for FET drivers  26 NB1 FET driver for 1ch	Pin No.		Function		
adjusting the BURST triangle oscillator  External capacitor from BCT to GND for adjusting the BURST triangle oscillator  External resistor from SRT to RT for adjusting the triangle oscillator  External resistor from SRT to RT for adjusting the triangle oscillator  External resistor from SRT to RT for adjusting the triangle oscillator  External capacitor from CT to GND for adjusting the triangle oscillator  RT GND GROUND  External capacitor from CT to GND for adjusting the triangle oscillator  REST Error amplifier output(1)  SET Error amplifier input(2)  Error amplifier input(2)  Error amplifier input(3)  Error amplifier input(3)  Error amplifier input(4)  VREF Reference voltage  Voltage difference or under voltage detect for 1ch  STB Stand-by switch  Voltage difference or under voltage detect for 1ch  COMPB1 Voltage difference or under voltage detect for 2ch  COMPB2 Voltage difference or under voltage detect for 2ch  External capacitor from SS to GND for Soft Start Control  External capacitor from SCP to GND for Timer Latch  External capacitor from SCP to GND for Timer Latch  PET driver for 2ch  REG Internal regulator output  External capacitor from SCP to GND for Timer Latch  RET driver for 2ch  RET driver for 1ch	. 1	DUTY	Control PWM mode and BURST mode		
adjusting the BURST triangle oscillator  External resistor from SRT to RT for adjusting the triangle oscillator  SRT External resistor from SRT to RT for adjusting the triangle oscillator  External capacitor from CT to GND for adjusting the triangle oscillator  External capacitor from CT to GND for adjusting the triangle oscillator  GND GROUND  B FB1 Error amplifier output①  SSI Error amplifier input①  SSI Error amplifier input②  SSI Error amplifier input②  SSI Error amplifier input④  SSI Error amplifier input④  VS2 Error amplifier input④  VS2 Error amplifier input④  VS2 Error amplifier input④  VS3 Error amplifier input④  VS4 COMPA1  VS5 Error amplifier output④  VS6 Error amplifier output④  VS7 Error amplifier output④  VS8 Error amplifier output④  VS9 Error amplifier input④  VS9 Error amplifier output④  VS9 Error amplifier output④  VOItage difference or under voltage detect for 1ch  VOItage difference or under voltage detect for 1ch  VOItage difference or under voltage detect for 2ch  SS External capacitor from SS to GND for Soft Start Control  External capacitor from SCP to GND for Timer Latch  SS PGND FET driver for 2ch  PGND Ground for FET drivers  NA1 FET driver for 1ch	2	BRT			
adjusting the triangle oscillator  External resistor from SRT to RT for adjusting the triangle oscillator  External capacitor from CT to GND for adjusting the triangle oscillator  RND GROUND  FB1 Error amplifier output(1)  SS1 Error amplifier input(2)  ISS Error amplifier input(2)  ISS Error amplifier input(3)  VS2 Error amplifier input(4)  VREF Reference voltage  Voltage difference or under voltage detect for 1ch  STB Stand-by switch  COMPA1 Voltage difference or under voltage detect for 1ch  COMPB2 Voltage difference or under voltage detect for 2ch  COMPB2 Voltage difference or under voltage detect for 2ch  SS External capacitor from SS to GND for Soft Start Control  External capacitor from SCP to GND for Timer Latch  NB2 FET driver for 2ch  PGND Ground for FET drivers  NB1 FET driver for 1ch	3	BCT			
adjusting the triangle oscillator  External capacitor from CT to GND for adjusting the triangle oscillator  GND GROUND  FB1 Error amplifier output(1)  SS1 Error amplifier input(2)  IS1 Error amplifier input(2)  IS2 Error amplifier output(2)  IS2 Error amplifier input(3)  VS2 Error amplifier input(4)  VREF Reference voltage  Voltage difference or under voltage detect for 1ch  STB Stand-by switch  COMPA1 Voltage difference or under voltage detect for 1ch  COMPB1 Voltage difference or under voltage detect for 2ch  COMPB2 Voltage difference or under voltage detect for 2ch  SS External capacitor from SS to GND for Soft Start Control  External capacitor from SCP to GND for Timer Latch  NB2 FET driver for 2ch  PGND Ground for FET drivers  NB1 FET driver for 1ch	4	RT	1		
adjusting the triangle oscillator  GND GROUND  B FB1 Error amplifier output①  SI Error amplifier input①  VS1 Error amplifier input②  IS2 Error amplifier output②  IS3 VS2 Error amplifier input④  VREF Reference voltage  Voltage difference or under voltage detect for 1ch  STB Stand-by switch  COMPB1 Voltage difference or under voltage detect for 1ch  COMPB2 Voltage difference or under voltage detect for 2ch  COMPB2 Voltage difference or under voltage detect for 2ch  SCP External capacitor from SS to GND for Soft Start Control  External capacitor from SCP to GND for Timer Latch  SCP GROUND Ground for FET drivers  ANA FET driver for 1ch  PET driver for 1ch  NA1 FET driver for 1ch	5	SRT			
8 FB1 Error amplifier output(1) 9 IS1 Error amplifier input(1) 10 VS1 Error amplifier input(2) 11 FB2 Error amplifier output(2) 12 IS2 Error amplifier input(3) 13 VS2 Error amplifier input(4) 14 VREF Reference voltage 15 COMPA1 Voltage difference or under voltage detect for 1ch 16 STB Stand-by switch 17 COMPB1 Voltage difference or under voltage detect for 1ch 18 COMPA2 Voltage difference or under voltage detect for 2ch 19 COMPB2 Voltage difference or under voltage detect for 2ch 20 REG Internal regulator output 21 SS External capacitor from SS to GND for Soft Start Control 22 SCP External capacitor from SCP to GND for Timer Latch 23 NA2 FET driver for 2ch 24 NB2 FET driver for 2ch 25 PGND Ground for FET drivers 26 NB1 FET driver for 1ch		СТ	External capacitor from CT to GND for		
9 IS1 Error amplifier input① 10 VS1 Error amplifier input② 11 FB2 Error amplifier output② 12 IS2 Error amplifier input③ 13 VS2 Error amplifier input④ 14 VREF Reference voltage 15 COMPA1 16 STB Stand-by switch 17 COMPB1 Voltage difference or under voltage detect for 1ch 18 COMPA2 Voltage difference or under voltage detect for 2ch 19 COMPB2 Voltage difference or under voltage detect for 2ch 20 REG Internal regulator output 21 SS External capacitor from SS to GND for Soft Start Control 22 SCP External capacitor from SCP to GND for Timer Latch 23 NA2 FET driver for 2ch 25 PGND Ground for FET drivers 26 NB1 FET driver for 1ch 27 NA1 FET driver for 1ch	7	GND	GROUND		
10 VS1 Error amplifier input② 11 FB2 Error amplifier output② 12 IS2 Error amplifier input③ 13 VS2 Error amplifier input④ 14 VREF Reference voltage 15 COMPA1 Voltage difference or under voltage detect for 1ch 16 STB Stand-by switch 17 COMPB1 Voltage difference or under voltage detect for 1ch 18 COMPA2 Voltage difference or under voltage detect for 2ch 19 COMPB2 Voltage difference or under voltage detect for 2ch 20 REG Internal regulator output 21 SS External capacitor from SS to GND for Soft Start Control 22 SCP External capacitor from SCP to GND for Timer Latch 23 NA2 FET driver for 2ch 24 NB2 FET driver for 2ch 25 PGND Ground for FET drivers 26 NB1 FET driver for 1ch 27 NA1 FET driver for 1ch	8	FB1	Error amplifier output①		
11 FB2 Error amplifier output(2) 12 IS2 Error amplifier input(3) 13 VS2 Error amplifier input(4) 14 VREF Reference voltage 15 COMPA1 Voltage difference or under voltage detect for 1ch 16 STB Stand-by switch 17 COMPB1 Voltage difference or under voltage detect for 1ch 18 COMPA2 Voltage difference or under voltage detect for 2ch 19 COMPB2 Voltage difference or under voltage detect for 2ch. 20 REG Internal regulator output 21 SS External capacitor from SS to GND for Soft Start Control 22 SCP External capacitor from SCP to GND for Timer Latch 23 NA2 FET driver for 2ch 24 NB2 FET driver for 2ch 25 PGND Ground for FET drivers 26 NB1 FET driver for 1ch 27 NA1 FET driver for 1ch	9	IS1	Error amplifier input①		
12 IS2 Error amplifier input③ 13 VS2 Error amplifier input④ 14 VREF Reference voltage 15 COMPA1 Voltage difference or under voltage detect for 1ch 16 STB Stand-by switch 17 COMPB1 Voltage difference or under voltage detect for 1ch 18 COMPA2 Voltage difference or under voltage detect for 2ch 19 COMPB2 Voltage difference or under voltage detect for 2ch 20 REG Internal regulator output 21 SS External capacitor from SS to GND for Soft Start Control 22 SCP External capacitor from SCP to GND for Timer Latch 23 NA2 FET driver for 2ch 24 NB2 FET driver for 2ch 25 PGND Ground for FET drivers 26 NB1 FET driver for 1ch 27 NA1 FET driver for 1ch	10	VS1	Error amplifier input②		
13 VS2 Error amplifier input(1)  14 VREF Reference voltage  15 COMPA1 Voltage difference or under voltage detect for 1ch  16 STB Stand-by switch  17 COMPB1 Voltage difference or under voltage detect for 1ch  18 COMPA2 Voltage difference or under voltage detect for 2ch  19 COMPB2 Voltage difference or under voltage detect for 2ch  20 REG Internal regulator output  21 SS External capacitor from SS to GND for Soft Start Control  22 SCP External capacitor from SCP to GND for Timer Latch  23 NA2 FET driver for 2ch  24 NB2 FET driver for 2ch  25 PGND Ground for FET drivers  26 NB1 FET driver for 1ch  27 NA1 FET driver for 1ch	11	FB2	Error amplifier output②		
14 VREF Reference voltage  15 COMPA1 Voltage difference or under voltage detect for 1ch  16 STB Stand-by switch  17 COMPB1 Voltage difference or under voltage detect for 1ch  18 COMPA2 Voltage difference or under voltage detect for 2ch  19 COMPB2 Voltage difference or under voltage detect for 2ch  20 REG Internal regulator output  21 SS External capacitor from SS to GND for Soft Start Control  22 SCP External capacitor from SCP to GND for Timer Latch  23 NA2 FET driver for 2ch  24 NB2 FET driver for 2ch  25 PGND Ground for FET drivers  26 NB1 FET driver for 1ch	12	IS2	Error amplifier input3		
15 COMPA1 Voltage difference or under voltage detect for 1ch 16 STB Stand-by switch 17 COMPB1 Voltage difference or under voltage detect for 1ch 18 COMPA2 Voltage difference or under voltage detect for 2ch 19 COMPB2 Voltage difference or under voltage detect for 2ch 20 REG Internal regulator output 21 SS External capacitor from SS to GND for Soft Start Control 22 SCP External capacitor from SCP to GND for Timer Latch 23 NA2 FET driver for 2ch 24 NB2 FET driver for 2ch 25 PGND Ground for FET drivers 26 NB1 FET driver for 1ch 27 NA1 FET driver for 1ch	13	VS2	Error amplifier input(4)		
detect for 1ch  STB Stand-by switch  COMPB1 Voltage difference or under voltage detect for 1ch  COMPB2 Voltage difference or under voltage detect for 2ch  COMPB2 Voltage difference or under voltage detect for 2ch  COMPB2 Voltage difference or under voltage detect for 2ch.  REG Internal regulator output  SS External capacitor from SS to GND for Soft Start Control  SCP External capacitor from SCP to GND for Timer Latch  NA2 FET driver for 2ch  FET driver for 2ch  COMPB2 COMPB2 Voltage difference or under voltage detect for 2ch.  SS External capacitor from SS to GND for Timer Latch  COMPB2 COM	14	VREF	Reference voltage		
16 STB Stand-by switch  17 COMPB1 Voltage difference or under voltage detect for 1ch  18 COMPA2 Voltage difference or under voltage detect for 2ch  19 COMPB2 Voltage difference or under voltage detect for 2ch  20 REG Internal regulator output  21 SS External capacitor from SS to GND for Soft Start Control  22 SCP External capacitor from SCP to GND for Timer Latch  23 NA2 FET driver for 2ch  24 NB2 FET driver for 2ch  25 PGND Ground for FET drivers  26 NB1 FET driver for 1ch  27 NA1 FET driver for 1ch	15	COMPA1			
detect for 1ch  COMPA2   Voltage difference or under voltage detect for 2ch  COMPB2   Voltage difference or under voltage detect for 2ch  COMPB2   Voltage difference or under voltage detect for 2ch.  COMPB2   Voltage difference or under voltage detect for 2ch.  COMPB2   SCOMPB2   Internal regulator output  COMPB2   STATE   COMPB2   CO	16	STB			
detect for 2ch  19 COMPB2 Voltage difference or under voltage detect for 2ch.  20 REG Internal regulator output  21 SS External capacitor from SS to GND for Soft Start Control  22 SCP External capacitor from SCP to GND for Timer Latch  23 NA2 FET driver for 2ch  24 NB2 FET driver for 2ch  25 PGND Ground for FET drivers  26 NB1 FET driver for 1ch  27 NA1 FET driver for 1ch	17	COMPB1			
detect for 2ch.  20 REG Internal regulator output  21 SS External capacitor from SS to GND for Soft Start Control  22 SCP External capacitor from SCP to GND for Timer Latch  23 NA2 FET driver for 2ch  24 NB2 FET driver for 2ch  25 PGND Ground for FET drivers  26 NB1 FET driver for 1ch  27 NA1 FET driver for 1ch	18	COMPA2			
21 SS External capacitor from SS to GND for Soft Start Control  22 SCP External capacitor from SCP to GND for Timer Latch  23 NA2 FET driver for 2ch  24 NB2 FET driver for 2ch  25 PGND Ground for FET drivers  26 NB1 FET driver for 1ch  27 NA1 FET driver for 1ch	19	COMPB2			
21 SS External capacitor from SS to GND for Soft Start Control  22 SCP External capacitor from SCP to GND for Timer Latch  23 NA2 FET driver for 2ch  24 NB2 FET driver for 2ch  25 PGND Ground for FET drivers  26 NB1 FET driver for 1ch  27 NA1 FET driver for 1ch	20	REG	Internal regulator output		
Timer Latch  23 NA2 FET driver for 2ch  24 NB2 FET driver for 2ch  25 PGND Ground for FET drivers  26 NB1 FET driver for 1ch  27 NA1 FET driver for 1ch	21	SS	External capacitor from SS to GND for		
24 NB2 FET driver for 2ch 25 PGND Ground for FET drivers 26 NB1 FET driver for 1ch 27 NA1 FET driver for 1ch	22	SCP			
25 PGND Ground for FET drivers 26 NB1 FET driver for 1ch 27 NA1 FET driver for 1ch	23	NA2	FET driver for 2ch		
26 NB1 FET driver for 1ch 27 NA1 FET driver for 1ch		NB2	FET driver for 2ch		
27 NA1 FET driver for 1ch	25	PGND	Ground for FET drivers		
11.1. 1.1. 1.1. 1.1. 1.1.		NB1	FET driver for 1ch		
28 Vcc Supply voltage input	27	NA1	FET driver for 1ch		
	28	Vcc	Supply voltage input		



#### ONOTE FOR USE

- 1. When designing the external circuit, including adequate margins for variation between external devices and IC. Use adequate margins for steady state and transient characteristics.
- 2. The circuit functionality is guaranteed within of ambient temperature operation range as long as it is within recommended operating range. The standard electrical characteristic values cannot be guaranteed at other voltages in the operating ranges, however the variation will be small.
- 3. Mounting failures, such as misdirection or miscounts, may harm the device.
- 4. A strong electromagnetic field may cause the IC to malfunction.
- 5. The GND pin should be the location within  $\pm 0.3V$  compared with the PGND pin.
- 6. BD9888F and BD9888FV incorporate a built-in thermal shutdown circuit (TSD circuit). The thermal shutdown circuit (TSD circuit) is designed only to shut the IC off to prevent runaway thermal operation. It is not designed to protect the IC or guarantee its operation of the thermal shutdown circuit is assumed.
- 7. Absolute maximum ratings are those values that, if exceeded, may cause the life of a device to become significantly shortened. Moreover, the exact failure mode caused by short or open is not defined. Physical countermeasures, such as a fuse, need to be considered when using a device beyond its maximum ratings.
- 8. About the external FET, the parasitic Capacitor may cause the gate voltage to change, when the drain voltage is switching. Make sure to leave adequate margin for this IC variation.
- 9. On operating Slow Start Control (SS is less than 2.2V), It does not operate Timer Latch.
- 1 0. By STB voltage, BD9888F and BD9888FV are changed to 2 states. Therefore, do not input STB pin voltage between one state and the other state  $(0.8 \sim 1.6)$ .
- 1 1. The pin connected a connector need to connect to the resistor for electrical surge destruction. This IC is a monolithic IC which (as shown is Fig-1) has P<sup>+</sup> substrate and between the various pins. A P-N junction is formed from this P layer of each pin. For example, the relation between each potential is as follows,
  - O(When GND > PinB and GND > PinA, the P-N junction operates as a parasitic diode.)
  - O(When PinB > GND > PinA, the P-N junction operates as a parasitic transistor.)

Parasitic diodes can occur inevitably in the structure of the IC. The operation of parasitic diodes can result in mutual interference among circuits as well as operation faults and physical damage. Accordingly you must not use methods by which parasitic diodes operate, such as applying a voltage that is lower than the GND (P substrate) voltage to an input pin.

- 1 2. This IC is a monolithic IC which (as shown is Fig-1)has P<sup>+</sup> substrate and between the various pins. A P-N junction is formed from this P layer of each pin. For example, the relation between each potential is as follows,
  - ○(When GND > PinB and GND > PinA, the P-N junction operates as a parasitic diode.)
  - O(When PinB > GND > PinA, the P-N junction operates as a parasitic transistor.)

Parasitic diodes can occur inevitably in the structure of the IC. The operation of parasitic diodes can result in mutual interference among circuits as well as operation faults and physical damage. Accordingly you must not use methods by which parasitic diodes operate, such as applying a voltage that is lower than the GND (P substrate) voltage to an input pin.




Fig-1 Simplified structure of a Bipolar IC

## Notes

- No technical content pages of this document may be reproduced in any form or transmitted by any
  means without prior permission of ROHM CO.,LTD.
- The contents described herein are subject to change without notice. The specifications for the
  product described in this document are for reference only. Upon actual use, therefore, please request
  that specifications to be separately delivered.
- Application circuit diagrams and circuit constants contained herein are shown as examples of standard
  use and operation. Please pay careful attention to the peripheral conditions when designing circuits
  and deciding upon circuit constants in the set.
- Any data, including, but not limited to application circuit diagrams information, described herein are intended only as illustrations of such devices and not as the specifications for such devices. ROHM CO.,LTD. disclaims any warranty that any use of such devices shall be free from infringement of any third party's intellectual property rights or other proprietary rights, and further, assumes no liability of whatsoever nature in the event of any such infringement, or arising from or connected with or related to the use of such devices.
- Upon the sale of any such devices, other than for buyer's right to use such devices itself, resell or
  otherwise dispose of the same, no express or implied right or license to practice or commercially
  exploit any intellectual property rights or other proprietary rights owned or controlled by
- ROHM CO., LTD. is granted to any such buyer.
- Products listed in this document are no antiradiation design.

The products listed in this document are designed to be used with ordinary electronic equipment or devices (such as audio visual equipment, office-automation equipment, communications devices, electrical appliances and electronic toys).

Should you intend to use these products with equipment or devices which require an extremely high level of reliability and the malfunction of with would directly endanger human life (such as medical instruments, transportation equipment, aerospace machinery, nuclear-reactor controllers, fuel controllers and other safety devices), please be sure to consult with our sales representative in advance.

### About Export Control Order in Japan

Products described herein are the objects of controlled goods in Annex 1 (Item 16) of Export Trade Control Order in Japan.

In case of export from Japan, please confirm if it applies to "objective" criteria or an "informed" (by MITI clause) on the basis of "catch all controls for Non-Proliferation of Weapons of Mass Destruction.





Thank you for your accessing to ROHM product informations.

More detail product informations and catalogs are available,
please contact your nearest sales office.

## Please contact our sales offices for details;

```
U.S.A / San Diego
                        TEL: +1(858)625-3630
                                                 FAX: +1(858)625-3670
       Atlanta
                        TEL: +1(770)754-5972
                                                 FAX: +1(770)754-0691
       Dallas
                        TEL: +1(972)312-8818
                                                 FAX: +1(972)312-0330
Germany / Dusseldorf
                        TEL: +49(2154)9210
                                                 FAX: +49(2154)921400
United Kingdom / London TEL: +44(1)908-282-666
                                                 FAX: +44(1)908-282-528
France / Paris
                        TEL: +33(0)1 56 97 30 60 FAX: +33(0) 1 56 97 30 80
China / Hong Kong
                        TEL: +852(2)740-6262
                                                 FAX: +852(2)375-8971
       Shanghai
                        TEL: +86(21)6279-2727
                                                 FAX: +86(21)6247-2066
       Dilian
                        TEL: +86(411)8230-8549
                                                 FAX: +86(411)8230-8537
       Beijing
                        TEL: +86(10)8525-2483
                                                 FAX: +86(10)8525-2489
Taiwan / Taipei
                        TEL: +866(2)2500-6956
                                                 FAX: +866(2)2503-2869
Korea / Seoul
                        TEL: +82(2)8182-700
                                                 FAX: +82(2)8182-715
Singapore
                        TEL: +65-6332-2322
                                                 FAX: +65-6332-5662
Malaysia / Kuala Lumpur
                        TEL: +60(3)7958-8355
                                                 FAX: +60(3)7958-8377
Philippines / Manila
                        TEL: +63(2)807-6872
                                                 FAX: +63(2)809-1422
Thailand / Bangkok
                        TEL: +66(2)254-4890
                                                 FAX: +66(2)256-6334
```

# Japan / (Internal Sales)

Tokyo 2-1-1, Yaesu, Chuo-ku, Tokyo 104-0082

TEL: +81(3)5203-0321 FAX: +81(3)5203-0300

Yokohama 2-4-8, Shin Yokohama, Kohoku-ku, Yokohama, Kanagawa 222-8575

TEL: +81(45)476-2131 FAX: +81(45)476-2128

Nagoya Dainagayo Building 9F 3-28-12, Meieki, Nakamura-ku, Nagoya, Aichi 450-0002

TEL: +81(52)581-8521 FAX: +81(52)561-2173

Kyoto 579-32 Higashi Shiokouji-cho, Karasuma Nishi-iru, Shiokoujidori, Shimogyo-ku,

Kyoto 600-8216

TEL: +81(75)311-2121 FAX: +81(75)314-6559

(Contact address for overseas customers in Japan)

Yokohama TEL: +81(45)476-9270 FAX: +81(045)476-9271